



VIBRATOR CARE INSTRUCTIONS

1. Take care when using the vibrator for the first time. Vibration can be intense.
2. Clean your vibrator after every use.
3. Take care when cleaning your vibrator. Remember it is an electrical item.
4. Keep your vibrator clean and dry. Store in a non-damp environment.
5. Always store your vibrator separately. Different materials have different chemical configurations and may react with each other.
6. Always allow your vibrator to cool down before storing in a safe place. Vibrators are electrical and motors grow warm with use.
7. Excessive usage of the vibrator will wear out the motor and may cause the motor to overheat. If you feel your vibrator is getting unduly hot, switch off and allow it to cool down, before continuing use.
8. Take care when using oils and lubricants so that they do not enter the battery compartment as they can react with the batteries.



CHARGING INSTRUCTIONS

This vibrator arrives with partial charge of 30 – 50%. It is recommended to use up this partial charge before fully recharging for the first time. This will ensure the longest possible battery life. Connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input.

Initial charge will take about 2 hours to complete, and subsequent charges will also take about 2 hours to complete.

The indicator light will be on while device is charging, and turn off when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 90 minutes of play time using the highest function setting.

This toy operates at a sound level of less than 60db. The battery operates at 500mAh.

INSTRUCTIONS FOR USE

This toy has an easy-to-use 2 button control panel. The bottom Power Button turns the toy off and on, and the top Function button cycles through 7 vibration speeds and patterns.

The shaft and clitoral piece have separate motors that operate together.

Press the bottom Power Button to turn both motors on by pressing it for at least 3 seconds. The LED lights will turn on and the shaft will begin vibrating at its lowest vibration.

Press the top Function Button to cycle through 7 different vibration speeds and functions in both motors together.

To turn off the motors, press the bottom Power Button for at least 3 seconds.

USB RECHARGEABLE

