

Product Specifications:

Category: Vibrator Material: Silicone Size: H: 108mm W: 50.75mm D: 35mm Battery: Liion battery, 3.7V/140mAh Voltage: 3.7V Number of Vibrations: 9 patterns vibration User time: 25°75 minutes Sound Level: <40 dbs

CHARGING INSTRUCTIONS

This vibrator arrives with a partial charge, but it is recommended to charge before use.

connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input.

toy's input.
Initial charge will take about 90
minutes, and subsequent charges will
also take about 90 minutes to complete.
The indicator light will flash while
device is charging, and remain solid
when toy is fully charged. There is no
danger of battery damage by
overcharging, but it's recommended
not to overcharge for long periods of
time.

time.
Charge lasts for about 75 minutes of play time on the lowest level of vibration, and about 25 minutes on the highest level. Toy vibration slowly reduces when charge begins to deplete.

begins to deplete.
This toy operates at a sound level of 40db
with a 3.7V battery

INSTRUCTIONS FOR USE

This toy has a convenient one-button control on the handle.

to turn toy on, press the button for at least 3 seconds. The light will turn on and toy will begin vibrating at its first lowest frequency. Once the toy is on, press the button a single time for each new speed or function for a total of 9

To turn toy off, press power button for at least 3 seconds.



USB RECHARGEABLE

