



<http://www.evolvednovelties.com/>



Product Specifications:

- Material: Silicone & ABS Plastic
- Battery: Lithium battery;
- Voltage: DC3.7V;
- Number of Vibrations: 7 rotating & vibrating modes;
- User time: About 50min
- Sound Level: ≤50 db

CHARGING INSTRUCTIONS

This vibrator arrives with low partial charge, so it is recommended to fully charge before use. Connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input.

Initial and subsequent charges take about 1.5 - 2 hours to complete.

The indicator light will be on while device is charging and turn off when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 55 minutes of play time on the lowest level of vibration, and about 45 minutes on the highest level.

This toy operates at a sound level of less than 50 db with a lithium battery at DC3.7V.

The remote operates at 1.5V with a AAA battery.

INSTRUCTIONS FOR USE

This toy can be operated by a 2-button control panel at the base of its shaft or a 3-button panel on the remote control.

TO OPERATE DIRECTLY ON TOY:

Use the bottom Power Button to turn the toy on by pressing it for at least 1.5 seconds. Both motors will engage at their lowest speeds and the LED light will flash. The motors work together. Note: The remote control must be turned on separately with its Power Button.

Use the bottom Power Button (with on/off symbol) pressed more quickly to cycle through seven (7) rotation and vibration functions. The LED light will flash to indicate each new speed.

Use the top Turbo Boost Button (with wavy lines) to engage Turbo Boost mode which will immediately deliver 10 seconds of maximum motor power, after which it will resume to the settings used most recently.

To turn off the toy, press the Power Button for at least 1.5 seconds.

Note: Turn off the remote control separately with its own Power Button.

TO OPERATE WITH REMOTE CONTROL:

Using the indicator light as the top of the remote, use the middle Power Button to turn the toy on by pressing it for at least 1.5 seconds. Both motors will engage at their lowest speeds. The motors work together.

Use the bottom Function Button (heart symbol) to cycle through seven (7) rotation and vibration speeds and functions.

Use the top Turbo Boost Button (wavy symbol) to engage Turbo Boost mode which will immediately deliver 10 seconds of maximum motor power, after which the motors will resume to the settings used most recently.

To turn off the toy, press the middle Power Button for at least 1.5 seconds.

HOW TO USE THE HANDS-FREE SUCTION CUP MOUNT:

Find a clean dry surface and press the powerful suction cup onto the surface until you feel a secure grip. Twist the base to loosen the grip and remove.



USB RECHARGEABLE