

<http://www.genderx.com/>

GENDER X



Product Specifications:

Material: Silicone
Battery: Li-ion battery,
3.7V/320mAh
Voltage: 3.7V
Number of Vibrations: 9
User time: 35-65 minutes
Sound Level: <45 db



CHARGING INSTRUCTIONS

This vibrator arrives with a low partial charge, so it is recommended to charge fully before use.

To charge, connect the USB plug into the USB port of your computer or other output and the magnetic DC charger into the two magnetic pins at the toy's base. Initial and subsequent charges will take about 30 minutes to complete.

The indicator light will flash while device is charging and turn off when toy is fully charged. There is no danger of battery damage by overcharging but it's recommended not to overcharge for long periods of time.

Charge lasts for about 35 minutes of play time at the highest level of vibration and about 65 minutes at the lowest level.

This toy operates at a sound level of less than 45db with a rechargeable 320mAh lithium battery at 3.7V.

INSTRUCTIONS FOR USE

This toy has a convenient 1-button control at its base.

To turn toy on, press the Power Button for at least 3 seconds. The lights will turn on and toy will begin vibrating at its first lowest frequency.

Once the toy is on, press the Power Button again, a single time for each new speed or function for a total of 9.

To turn toy off, press Power Button for at least 3 seconds.

ATTACH USB CHARGER TO PRONGS

USB RECHARGEABLE

