

<http://www.evalvednovelties.com/>

EVOLVED
Love is Back



Product Specifications:

Material: Premium silicone and ABS

Battery: Poly Li-ion battery 902040 700mAh

Voltage: 3.7V

Number of Vibrations: 10

modes of vibrating *3 motors
User time: Around 45-60 minutes

Sound Level: ≤60db @50cm

CHARGING INSTRUCTIONS: This vibrator arrives with partial charge, so it is recommended to charge the toy before first use.

Connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input, located below the removeable shaft part on the butterfly stimulator shaft.

Initial and subsequent charges will take about 2 hours to complete.

The indicator light will flash on toy while device is charging and become solid when toy is fully charged. There is no danger of battery damage by overcharging but it's recommended not to overcharge for long periods of time.

Charge lasts for about an hour at the lowest levels of vibration, and about 45 minutes at the highest levels of vibration.

This toy operates at a sound level of less than 60db with a 700mAh lithium battery at a voltage of 3.7V.

INSTRUCTIONS FOR USE: This toy is operated with a 3-button control panel located on the butterfly stimulator shaft. Each button controls its own motor. The top button controls the 'wearable' shaft, the middle button controls the butterfly stimulator, and the bottom button controls the removeable shaft.

Press the top button for at least 2 seconds to engage the vibration in the wearable shaft. The light will turn on and it will begin vibrating at its lowest frequency. Press again to cycle through 10 vibration speeds and functions. Press again for 2 seconds to turn this function off.

Press the middle button for at least 2 seconds to engage the vibration in the butterfly stimulator shaft. The light will turn on and it will begin vibrating at its lowest frequency. Press again to cycle through 10 vibration speeds and functions. Press again for 2 seconds to turn this function off.

Press the bottom button for at least 2 seconds to engage the vibration in the removeable shaft. The light will turn on and it will begin vibrating at its lowest frequency. Press again to cycle through 10 vibration speeds and functions. Press again for 2 seconds to turn this function off.

